

DTC	C1201/51	ENGINE CONTROL SYSTEM MALFUNCTION
------------	-----------------	--

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1201/51	Conditions 1. and 2. continue for 5 sec.: 1. Engine speed: 500 rpm or more. 2. A trouble signal in the engine control system is input.	Engine control system

HINT:

If trouble occurs in the engine control system, the ECU prohibits TRAC and VSC control.

INSPECTION PROCEDURE

1	CHECK DTC FOR ENGINE
----------	-----------------------------

(a) Check if the DTC of engine.

A	Always ON
B	Malfunction code

B	REPAIR CIRCUIT INDICATED BY OUTPUT CODE
----------	--

A

CHECK ENGINE WARNING LIGHT CONDITION
