

## FUEL PUMP

### ON-VEHICLE INSPECTION

SF0N2-02

#### 1. CHECK FUEL PUMP OPERATION

- (a) Connect a hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and hand-held tester main switch ON.


#### NOTICE:

**Do not start the engine.**

- (c) Select the ACTIVE TEST mode on the hand-held tester.
- (d) Please refer to the hand-held tester operator's manual for further details.
- (e) If you have no hand-held tester, connect the positive (+) and negative (-) leads from the battery to the fuel pump connector. (See step 3)
- (f) Check that the pulsation damper screw rises up when the fuel pump operates.

If there is no pressure, check these parts:

- Fusible link
  - Fuses
  - EFI main relay
  - Fuel pump ECU
  - Fuel pump
  - Engine ECU
  - Wiring connections
- (g) Turn the ignition switch OFF.
  - (h) Disconnect the hand-held tester from the DLC3.




#### 2. CHECK FUEL PRESSURE


- (a) Check the battery positive voltage is above 12 V.
- (b) Disconnect the negative (-) terminal cable from the battery.
- (c) Remove the union bolt and 2 gaskets, and disconnect the fuel inlet hose from the fuel pipe support.

#### NOTICE:

- **Put a shop towel under the fuel pipe support.**
- **Slowly loosen the union bolt.**



- (d) Install the fuel inlet hose and SST (pressure gauge) to the fuel pipe support with the 3 gaskets and SST (union and adapter).  
SST 09268-45014 (09268-41190, 90405-06167)  
**Torque: 29 N·m (300 kgf·cm, 21 ft·lbf)**
- (e) Wipe off any splattered gasoline.



- (f) Connect a hand-held tester to the DLC3.  
(See step 1 in check fuel pump operation (a) to (e))
- (g) Measure the fuel pressure.

**Fuel pressure:****304 – 343 kPa (3.1 – 3.5 kgf/cm<sup>2</sup>, 44 – 50 psi)**

If pressure is high, replace the fuel pressure regulator.

If pressure is low, check these parts:

- Fuel hoses and connections
- Fuel pump
- Fuel filter
- Fuel pressure regulator

- (h) Disconnect the hand-held tester from the DLC3.

- (i) Start the engine.

- (j) Measure the fuel pressure at idle.

**Fuel pressure:****304 – 343 kPa (3.1 – 3.5 kgf/cm<sup>2</sup>, 44 – 50 psi)**

- (k) Stop the engine.

- (l) Check that the fuel pressure remains as specified for 5 minutes after the engine has stopped.

**Fuel pressure: 147 kPa (1.5 kgf/cm<sup>2</sup>, 21 psi) or more**

If pressure is not as specified, check the fuel pump, pressure regulator and/or injectors.

- (m) After checking fuel pressure, disconnect the negative (-) terminal cable from the battery and carefully remove SST to prevent gasoline from splashing.


SST 09268-45014

- (n) Reconnect the fuel inlet hose to the fuel pipe support with 2 new gaskets and the union bolt.

**Torque: 29 N·m (300 kgf·cm, 21 ft·lbf)**

- (o) Reconnect the negative (-) terminal cable to the battery.


- (p) Check for fuel leaks.

**3. INSPECT FUEL PUMP**

- (a) Remove the rear seat cushion.
- (b) Remove the 3 cap nuts and floor service hole cover.
- (c) Disconnect the fuel pump & sender gauge connector.
- (d) Using an ohmmeter, measure the resistance between terminals 4 and 5.

**Resistance: 0.2 – 3.0 Ω at 20°C (68°F)**

If the resistance is not as specified, replace the fuel pump.



- (e) Inspect the fuel pump operation. Connect the positive (+) lead from the battery to terminal 4 of the connector, and the negative (-) lead to terminal 5. Check that the fuel pump operates.

**NOTICE:**

- **These tests must be done quickly (within 10 seconds) to prevent the coil burning out.**
- **Keep the fuel pump as far away from the battery as possible.**
- **Always do the switching at the battery side.**

If operation is not as specified, replace the fuel pump.

- (f) Reconnect the fuel pump & sender gauge connector.  
(g) Reinstall the floor service hole cover with the cap nuts.  
(h) Reinstall the rear seat cushion.