


DTC	C0200/31	Right Front Wheel Speed Sensor Signal Malfunction
DTC	C0205/32	Left Front Wheel Speed Sensor Signal Malfunction
DTC	C0210/33	Right Rear Wheel Speed Sensor Signal Malfunction
DTC	C0215/34	Left Rear Wheel Speed Sensor Signal Malfunction
DTC	C1235/35	Foreign Object is Attached on Tip of Front Speed Sensor RH
DTC	C1236/36	Foreign Object is Attached on Tip of Front Speed Sensor LH
DTC	C1238/38	Foreign Object is Attached on Tip of Rear Speed Sensor RH
DTC	C1239/39	Foreign Object is Attached on Tip of Rear Speed Sensor LH

DESCRIPTION



C108865E02

The speed sensor detects wheel speed and sends the appropriate signals to the ECU. These signals are used for control of the vehicle stability control system. The front and rear rotors each have 48 serrations.


When the rotors rotate, the magnetic field emitted by the permanent magnet in the speed sensor generates AC voltage. Since the frequency of this AC voltage changes in direct proportion to the speed of the rotor, the frequency is used by the ECU to detect the speed of each wheel.

DTC No.	DTC Detection Condition	Trouble Area
C0200/31 C0205/32 C0210/33 C0215/34	<p>Detection of any of the conditions 1. through 4.:</p> <ol style="list-style-type: none"> 1. At a vehicle speed of 10 km/h (6 mph) or more, pulses are not input for 15 sec. 2. Momentary interruption of the speed sensor signal occurs at least 7 times in the time between switching the ignition switch ON and switching it OFF. 3. Continuous noise occurs in the speed sensor signals with a vehicle speed at 20 km/h (12 mph) or more. 4. The condition that the speed sensor signal circuit is open continues for 0.12 sec. or more. <ul style="list-style-type: none"> • ABS does not function • Brake pedal is not depressed • Parking brake is not set • Rear differential does not lock <p>Under the above conditions, when the difference in velocity between the highest rotating and the second highest rotating wheels is within 2 km/h (1 mph), the slowest wheel rotates at 0 km/h(0 mph), and the second slowest wheel rotates at 12 km/h (7 mph) for 1 second or more.</p>	<ul style="list-style-type: none"> • Right front, left front, right rear and left rear speed sensor • Each speed sensor circuit • Sensor rotor
C1235/35 C1236/36 C1238/38 C1239/39	<p>Continuous noise occurs in the speed sensor signals with a vehicle speed at 20 km/h (12 mph) or more continues for 5 sec. or more.</p>	<ul style="list-style-type: none"> • Right front, left front, right rear, left rear speed sensor • Speed sensor rotor

HINT:

- DTC C0200/31 and C1235/35 are for the right front speed sensor.
- DTC C0205/32 and C1236/36 are for the left front speed sensor.
- DTC C0210/33 and C1238/38 are for the right rear speed sensor.
- DTC C0215/34 and C1239/39 are for the left rear speed sensor.

WIRING DIAGRAM



HINT:

When using the intelligent tester, start from *1. When not using the intelligent tester, start from *2.

1 READ DATA LIST (FRONT SPEED SENSOR)*1

(a) Check the DATA LIST for proper functioning of the front speed sensor.

Skid control ECU assembly

Item	Measurement Item / Range (Display)	Normal Condition	Diagnostic Note
WHEEL SPD FR	Front right wheel speed / Min.: 0 km/h, Max.: 326.4 km/h	Actual wheel speed	Speed indicated on speedometer
WHEEL SPD FL	Front left wheel speed / Min.: 0 km/h, Max.: 326.4 km/h	Actual wheel speed	Speed indicated on speedometer
WHEEL SPD RR	Front right wheel speed / Min.: 0 km/h, Max.: 326.4 km/h	Actual wheel speed	Speed indicated on speedometer
WHEEL SPD RL	Front left wheel speed / Min.: 0 km/h, Max.: 326.4 km/h	Actual wheel speed	Speed indicated on speedometer

OK:

There is almost no difference in the displayed speed value.

HINT:

There is tolerance of +- 10% in the speedometer indication.

OK → **Go to step 4**

NG

2 INSPECT SPEED SENSOR*2

(a) Disconnect the A11 and A12 sensor connectors.
(b) Measure the resistance of the sensors.


Standard resistance:


LH

Tester Connection	Specified Condition
2 (FL+) - 4 (FL-)	0.92 to 1.22 kΩ
2 (FL+) - Body ground	10 kΩ or higher
4 (FL-) - Body ground	10 kΩ or higher

RH

Tester Connection	Specified Condition
1 (FR+) - 2 (FR-)	0.92 to 1.22 kΩ
1 (FR+) - Body ground	10 kΩ or higher
2 (FR-) - Body ground	10 kΩ or higher





- (c) Disconnect the A36 and A37 sensor connectors.
- (d) Measure the resistance of the sensors.

Standard resistance:
LH

Tester Connection	Specified Condition
1 (RL+) - 2 (RL-)	1.0 to 1.4 kΩ
1 (RL+) - Body ground	10 kΩ or higher
2 (RL-) - Body ground	10 kΩ or higher

RH

Tester Connection	Specified Condition
1 (RR+) - 2 (RR-)	1.0 to 1.4 kΩ
1 (RR+) - Body ground	10 kΩ or higher
2 (RR-) - Body ground	10 kΩ or higher

HINT:

Check the speed sensor signal after the speed sensor replacement.

NG → **REPLACE SPEED SENSOR**


OK

3 CHECK WIRE HARNESS (SKID CONTROL ECU - SPEED SENSOR)

NG → **REPAIR OR REPLACE HARNESS AND CONNECTOR**

OK

4 INSPECT SPEED SENSOR INSTALLATION



- (a) Check the speed sensor installation.

OK:

The installation bolt is tightened properly and there is no clearance between the sensor and front steering knuckle or rear axle carrier.

Torque: 8.0 N*m (82 kgf*cm, 71 in.*lbf)


HINT:

Check the speed sensor signal last.

NG → **SECURELY REINSTALL SENSOR**

OK

5 INSPECT SPEED SENSOR AND SENSOR ROTOR SERRATIONS



- Remove the skid control ECU with the connectors still connected.
- Connect the oscilloscope to each of terminals FR+ and FR-, FL+ and FL-, RR+ and RR-, or RL+ and RL- of the skid control ECU.
- Drive the vehicle at about 20 km/h (12 mph), and check the signal waveform.

HINT:


- As vehicle speed (km/h (rpm) of the wheels) increase, a cycle of the waveform narrows and the fluctuation in the output voltage becomes greater.
- When noise is identified in the waveform on the oscilloscope, error signals are generated due to speed sensor rotor scratches, looseness or foreign matter deposited on it.

OK

REPLACE SKID CONTROL ECU

NG

6 INSPECT SPEED SENSOR ROTOR AND SENSOR TIP



Front:

- Remove the front axle hub.
- Check the sensor rotor serrations.

OK:

No scratches, missing teeth or foreign matter.


- Remove the front speed sensor.
- Check the sensor tip.

OK:

No scratches or foreign matter on the sensor tip.

HINT:

If foreign matter (including that on the sensor rotor side) is identified, remove it and after reassembling, check the output waveform.



Rear:

- Remove the rear axle shaft.
- Check the sensor rotor serrations.

OK:

No scratches, missing teeth or foreign matter.

- Remove the rear speed sensor.
- Check the sensor tip.

OK:

No scratches or foreign matter on the sensor tip.

HINT:

- If foreign matter (including that on the sensor rotor side) is identified, remove it and after reassembling, check the output waveform.
- Check the speed sensor signal last.

NG

REPLACE SPEED SENSOR ROTOR

OK

REPLACE SKID CONTROL ECU ASSEMBLY