
Installation Manual Po-40 : Remote Control Mirror Toyota Camry ACV40 (2007-2011)



Checking the Package Contents

Main Control Unit





1. please make sure that ignition switch is OFF. Remove driver door scruff plate.




2. Remove cowl side trim clip and then remove cowl side trim.




COWL SIDE TRIM SUB-ASSEMBLY RH
COWL SIDE TRIM CLIP
FRONT DOOR SCUFF PLATE RH

3. Behide the cowl side trim , there is a white connector that we will work on it.



4. Disconnect connector [C]

remove the insulator of GREY wire of the connector [C]			
connect <u>Red</u> wire of Po-40 harness	to	GREY wire of Connector [C]	
remove the insulator of BLUE wire of the connector	[C]		
connect <u>Blue</u> wire of Po-40 harness	to	BLUE wire of Connector [C]	
remove the insulator of GREEN wire of the connector [C]			
connect White wire of Po-40 harness	to	GREEN wire of Connector [C]	



5. Wrap every junction by electrical tape.




6. Remove screws

(one on left side near center console and one on right side behide cowl side trim) and then remove lower instrument panel finish panel.



LOWER INSTRUMENT PANEL FINISH PANEL


7. Disconnect connector [A] (a white 9-wire type) behide mirror control switch.




connect the connector [A] of your car
connect the connector (TF) of T-quick harness

to connnector (TM) of T-quick harness

to the Mirror Switch





main function of the Po-40 Control Unit

With key switch OFF and every doors closed

Lock by Remote , key , button on door handle \rightarrow Mirror Retract

Unlook by Remote , key , button on door handle \rightarrow Mirror Extend

With key switch Acc or ON

Lock / Unlock does not control Mirror to Retract or Extend

but you can Retract/Extend outside mirror by Retact switch .



Copyright © 2008 Po-40 All rights reserved.

Spectial function of the Po-40 Control Unit

1. Door Lock but Mirror not Retract

(The car lock but the mirrors remain extended)

- key switch off
- close every doors (doors still unlock)
- Press Unlock button and then press Lock button on your remote (with in 1 second)
- 2. Door Unlock but Mirror not Extend (The car unlock but the mirrors remain retracted)
 - come back to the car (door still lock)
 - Press Lock button and then press Unlock button on your remote (with in 1 second)

Now you can enter the car but mirrors are still retracted,

they will extend when the key switch Acc or ON

Special functions are one-time functions. only on the situation you press Lock and then Unlock consecutivly or Unlock and then Lock consecutivly,

5 seconds after that the control box will reset to normal operation automatically.

On the harness there is black shrink tube wrap around it (Fuse inside)

if you install every thing correctly but the control box does not operate

please remove the black shrink tube and inspect if the fuse holder loose or diconnected.

