2004 VEHICLE IDENTIFICATION NUMBER

Vehicle Description Section (VDS)

World Manufacturer Identifier (WMI)

Check Digit

(VIS) Vehicle Indicator Section

JT2 DG12T OXO 049506

Digits

1. World Source:
J = Japan
2 = Canada: TMMC

2. Manufacturer:
T = Toyota

3. Vehicle Type:
8 = Passenger Vehicle
H = Passenger Vehicle
J = Multipurpose Passenger Vehicle
2 = Multipurpose Passenger Vehicle

4. Body Type/Drive Type:
Passenger Vehicle:
B = 4Dr Sedan 2WD
E = 4Dr Wagon 2WD
F = 2Dr Convertible 2WD
H = 4Dr Wagon 4WD

Multipurpose Passenger Vehicle:
B = 5Dr Wagon 4WD
G = 4Dr Wagon 2WD, 5Dr Wagon 2WD
H = 4Dr Wagon 4WD, 5Dr Wagon 4WD

5. Engine Family:
A = 3MZ-FE N = 3UZ-FE
D = 2JZ-GE T = 2UZ-FE
L = 3UZ-FE

6. Series:
0 = UZJ100L (LX470)
1 = JCE10L (IS300)
2 = UZJ120L (GX470)
3 = MCV31L (ES330)
MCU33L (RX330)
MCU38L (RX330)
UCF30L (LS430)
4 = UZZ40L (SC430)
6 = JZS160L (GS300)
UZS161L (GS430)

7. Restraint System/Grade:
Passenger Vehicle:
0 = Manual Belts w/ 2 Airbags, Side Airbags, and Curtain Shield Airbags (Front & Rear Seats)
6 = Manual Belts w/ 2 Airbags, Side Airbags Curtain Shield Airbags
8 = Manual Belt w/ 2 Airbags and Side Airbags
9 = Manual Belts w/ 2 Airbags, Side Airbags, and Curtain Shield Airbags (Front Seat Only)

Multipurpose Passenger Vehicle:
1 = STD

8. Car Line:
F = LS430 W = LX470
G = ES330 X = GX470
S = GS300 Y = SC430
GS430 2 = IS300
U = RX330

9. Check Digit:
Internal use only. Used by Toyota and FBI computers to verily the VIN.

10. Model Year:
4 = 2004

11. Plant Code:
0-9 = TMC
C = Canada

Digits

12-17. Serial Number